



Est 1990

# Bolt/Flange nut





Only one bolt model is required for mounting your X-Tray system.

One M8 carriage bolt with a square shoulder to save you having to hold against when you tighten the nut. The bags are stand-up and re-closable.



# Models

---

ARTICLES / DESCRIPTION	SURFACE TREATMENT
 <b>2761</b> X61 Bolt M8x27	Black Zink
 <b>2762</b> X62 Flange Nut M8	Black Zink
 <b>7100-031</b> Expander Bolt M8x65	Zinc Plated
 <b>7100-070</b> Self drilling screw, washer head 4.2x19	Zinc Plated